




Contactless reader

Reads available data from automotive CANbus and transmits it in original format to telematics unit



Basic solution for light commercial vehicles and personal cars




Insulation of wires without damage



Safe data reading through insulation of wires

- no influence on CAN bus operation
- power supply from onboard network
- easy installation and operation
- no preconfiguration needed
- compact and lightweight

Supply voltage 9 V ... 36 V
Current consumption not more 12.5 mA
Operating temperature -40°C ... +85°C
Weight not more 50 g



1. Put CANCrocoLITE between CAN H and CAN L wires
2. Fix wires with plastic cable ties
3. Connect CANCrocoLITE to telematics unit and power supply

Installation